


Our patented ActionDisc™ simply slides on the line before tying on your bait. Water pressure on the cupped surface of the disc causes it to wobble back and forth like a stop sign in a hurricane.




The energy created jerks the head of the bait from side to side giving it a natural swimming action and strike inducing vibration.



ActionDisc™ - Series I

Designed for use with lighter fresh water baits and flies. Recommended for plastic worms up to 5" in length and flies, squid lures or bait fish up to 3".



ActionDisc™ - Series II

For use with larger fresh water and light salt water baits and flies. Designed for plastic worms up to 10" in length and flies, squid lures or bait fish up to 5".



Order Online!

We are proud to have one of the best tackle related sites on the web. To get more information about ActionDiscs™ or to place an order go to :

www.wigglesfin.com

To place an order by phone call :
208/388-8539



WigglesFin, Inc. • 2109 Madison Ave. • Boise, ID 83702



TROUT


RIGGING GUIDE

Activate your favorite trout rigs with frantic vibration & wiggle-action!





ActionDiscs simply slide on the line before you tie on a bait or fly.



They produce truly unique action in light lures or flies that normally rely on the movement of the material or skilled manipulation by the angler to bring out their best.



ActionDiscs add the natural swimming action and vibration that has become increasingly important to catch trophy fish in heavily fished waters.

Trolling

Trolling flies ... and more recently soft plastic grubs and squid baits are rapidly growing in popularity with trout anglers.

For trolling ActionDiscs we recommend placing a barrel swivel 36" ahead of the bait or fly.

For light-line applications (under 8lb test) place a small bead between the ActionDisc and your bait or fly to eliminate any abrasion of the knot.



Casting

ActionDiscs provide a nice even wiggle with a steady retrieve. A quick jerk of the rod tip sends the bait into a panicked frenzy and the buzzing vibration of the disc is a killer strike trigger.

Slide a small egg sinker or cone weight on the line in front of the ActionDisc for casting. The sinker provides the weight needed to cast the bait without a spinning bubble and keeps the disc from running up the line on the cast.